



Fundumantal of Electronic II

Second Class

Chapter 6 : Field Effect Transistors

Lec06_p1

Munther N. Thiyab

2019-2020




FETs vs. BJTs

Similarities:

- Amplifiers
- Switching devices
- Impedance matching circuits

Differences:

- FETs are voltage controlled devices. BJTs are current controlled devices.
- FETs have a higher input impedance. BJTs have higher gains.
- FETs are less sensitive to temperature variations and are more easily integrated on ICs.





FET Types

- **JFET:** Junction FET
- **MOSFET:** Metal–Oxide–Semiconductor FET
 - **D-MOSFET:** Depletion MOSFET
 - **E-MOSFET:** Enhancement MOSFET

JFET Construction


There are two types of JFETs

- *n*-channel
- *p*-channel

The *n*-channel is more widely used.

There are three terminals:

- **Drain (D)** and **Source (S)** are connected to the *n*-channel
 - **Gate (G)** is connected to the *p*-type material
- Water analogy for the JFET control mechanism.




JFET Operating Characteristics:

$V_{GS} = 0\text{ V}$, V_{DS} some positive value

When $V_{GS} = 0$ and V_{DS} is increased from 0 to a more positive voltage:


- The depletion region between p-gate and n-channel increases.
- Increasing the depletion region, decreases the size of the n-channel which increases the resistance of the n-channel.
- Even though the n-channel resistance is increasing, the current (I_D) from source to drain through the n-channel is increasing. This is because V_{DS} is increasing.





JFET Operating Characteristics:

$V_{GS} = 0 \text{ V}$, V_{DS} some positive value




I_D versus V_{DS} for $V_{GS} = 0 \text{ V}$.



JFET Operating Characteristics: Pinch Off

If $V_{GS} = 0$ and V_{DS} is further increased to a more positive voltage, then the depletion zone gets so large that it **pinches off** the n-channel.

As V_{DS} is increased beyond $|V_P|$, the level of I_D remains the same ($I_D = I_{DSS}$).




I_{DSS} is the maximum drain current for a JFET and is defined by the conditions $V_{GS}=0$ and $V_{DS} > |V_P|$.

JFET Operating Characteristics , $V_{GS} < 0$

- As V_{GS} becomes more negative, the depletion region increases.
- The more negative V_{GS} , the resulting level for I_D is reduced.
- Eventually, when $V_{GS} = V_P$ (-ve) [$V_P = V_{GS(off)}$], I_D is 0 mA. (the device is “**turned off**”).


• The level of V_{GS} that results in $I_D = 0$ mA is defined by $V_{GS} = V_P$, with V_P being a negative voltage for n-channel devices and a positive voltage for p-channel JFETs.



Application of a negative voltage to the gate of a JFET.



JFET Operating Characteristics




n-Channel JFET characteristics with $I_{DSS} = 8$ mA and $V_P = -4$ V.



JFET Operating Characteristics: Voltage-Controlled Resistor

•The region to the left of the pinch-off point is called the **ohmic region**.

•The JFET can be used as a variable resistor, where V_{GS} controls the drain-source resistance (r_d). As V_{GS} becomes more negative, the resistance (r_d) increases.




$$r_d = \frac{r_o}{\left(1 - \frac{V_{GS}}{V_P}\right)^2}$$

where r_o is the resistance with $V_{GS}=0$ and r_d is the resistance at a particular level of V_{GS} .



p-Channel JFETs

The p -channel JFET behaves the same as the n -channel JFET, except the voltage polarities and current directions are reversed.






p-Channel JFET Characteristics

As V_{GS} increases more positively

- The depletion zone increases
- I_D decreases ($I_D < I_{DSS}$)
- Eventually $I_D = 0$ A



Also note that at high levels of V_{DS} the JFET reaches a breakdown situation: I_D increases uncontrollably if $V_{DS} > V_{DSmax}$.